


FortisBC Electric Transmission System Map



Locations of Electric transmission features shown on this map are approximate only. Accuracy, completeness, correctness, and currency are not guaranteed. Persons utilizing the map agree and accept that their use of any information contained therein is entirely at their own risk. FortisBC will not accept responsibility for any errors or omissions. You are required to call BC OneCall at 1-800-474-6886 prior to commencing any excavation.


Map Source Data: Natural Resources Canada, Province of British Columbia, FortisBC, BC Hydro, ICI Society
 Map Projection: BC Albers Equal Area Conic, NAD 1983



Legend

- Substations With Line Terminations
- Terminals & Switching Stations
- Generating Stations
- FortisBC 63 kV Lines
- FortisBC 161 kV Lines
- FortisBC 138 kV Lines
- FortisBC 230 kV Lines

Map Version: R11.0 Revision Date: August, 2024



Esri, HERE, Garmin, USGS, EPA, NPS, NRCAN, Esri, HERE, NPS